

REMOTE CONTROLS COMPATIBILITY CHART

MANUFACTURER	CAMERA MODEL	REMOTE CONTROLS									NOTES
		MVR901 ECPL Stand-by, Rec, Zoom	MVR901 ECLA Stand-by, Rec, Zoom Focus	MVR901 EPLA Stand-by, Rec, Zoom Focus, Iris (1*), Rec review	MVR901 ECEX Rec, Zoom, Fast Zoom Rec Review	MVR901 EPEX Rec, Zoom, Fast Zoom Rec Review	MVR911 ECCN Rec, Shutter release, Focus, LV on/off, LV zoom, Focus memory	MVR911 EICN Rec, Shutter release, Focus, LV on/off, LV zoom, Focus memory, ISO, Aperture, Shutter speed, Colour temp, Exposure comp	522AV Adaptor cable jack 2.5mm to Sony AV		
SONY	PMW-150										
SONY	PMW-200										
SONY	PMW-300										
SONY	PMW-EX280										
SONY	PMW-EX3										
SONY	PMW-EX1R										
SONY	PMW-EX1										
SONY	PXW-F57	• L	•	•							
SONY	HXR-MC2000	• L	•	•							
SONY	HXR-MC2500	• L	•	•							
SONY	HXR-MC50	• L	•	•							
SONY	HXR-NX30	• L	•	•							
SONY	HXR-NX3D1	• L	•	•							
SONY	HXR-NX3	• L	•	•							
SONY	HXR-NX5	• L	•	•							(10*)
SONY	HXR-NX70	• L	•	•							(10*)
SONY	NEX-EA50	• L	•	•							(2*)
SONY	NEX-FS100	• L	•	•							(2*)
SONY	NEX-FS700	• L	•	•							(2*)
SONY	NEX-VG20	• L	•	•							
SONY	NEX-VG30	• L	•	•							
SONY	NEX-VG900	• L	•	•							
SONY	HVR-A1	• L	•	•							
SONY	HVR-HD1000	• L	•	•							
SONY	HVR-S270	• L	•	•							
SONY	HVR-V1	• L	•	•							
SONY	HVR-Z5	• L	•	•							
SONY	HVR-Z7	• L	•	•							
SONY	HVR-Z1	• L	•	•							
SONY	HDR-AX2000	• L	•	•							
SONY	HDR-FX1	• L	•	•							
SONY	HDR-FX7	• L	•	•							
SONY	HDR-FX1000	• L	•	•							
SONY	DSR-PD175P	• L	•	•							
SONY	DCR-DVdxxx	• L	•	•							
SONY	DCR-SRxx	• L	•	•							
SONY	DCR-Sxxx (except DCR-SX22E)	• L	•	•							
SONY	DCR-Cxxx	• L	•	•							
SONY	DCR-VX2000	• L	•	•							
SONY	HDR-SRxx	• L	•	•							
SONY	HDR-TGxx	• L	•	•							
SONY	HDR-TD30V	• L	•	•							
SONY	HDR-XRxx	• L	•	•							
SONY	HDR-UX10	• L	•	•							
Canon	EOS C100	• L	•	•							(3*)
Canon	EOS C300	• L	•	•							(4*)
Canon	EOS C500	• L	•	•							(4*)
Canon	XF305	• L	•	•							
Canon	XF300	• L	•	•							
Canon	XF205	• L	•	•							
Canon	XF200	• L	•	•							
Canon	XF105	• L	•	•							
Canon	XF100	• L	•	•							
Canon	XA10	• L	•	•							(5*)
Canon	XA20	• L	•	•							(5*)
Canon	XA25	• L	•	•							(5*)
Canon	XL H1S	• L	•	•							
Canon	XL H1A	• L	•	•							
Canon	XH A1/A1S	• L	•	•							
Canon	XH G1/G1S	• L	•	•							
Canon	XL H1	• L	•	•							
Canon	XM1 / XM2	• L	•	•							
Canon	GL1 / GL2	• L	•	•							
Canon	HF-G25	• L	•	•							
Canon	HF-G30	• L	•	•							
Canon	EOS 1Dx						•		•		
Canon	EOS 1Dc						•		•		
Canon	EOS 6D						•		•		
Canon	EOS 5D mkIII						•		•		
Canon	EOS 5D mkII						•		•		
Canon	EOS 70D						•		•		
Canon	EOS 60D						•		•		
Canon	EOS 1D mkIV						•		•		
Canon	EOS 7D						•		•		
Canon	EOS 600D						•		•		
Canon	EOS 550D						•		•		
Canon	EOS 500D						•		•		
Panasonic	AG-3DA1	• P									(6*)
Panasonic	AG-3DP1	• P									(6*)
Panasonic	HDC-Z10000	• P									(6*)
Panasonic	AG-AC130/130A	• P									(6*)
Panasonic	AG-AC160/160A	• P									(6*)
Panasonic	AG-AC90	• P									(6*)
Panasonic	AG-AF100/101/100A	• P									(6*)
Panasonic	AG-HMC150/151/150PJ	• P									(6*)
Panasonic	AG-HMC40/41/40PJ	• P									(6*)
Panasonic	AG-HMC80/81/80PJ	• P									(6*)
Panasonic	AG-HPX250/255/250PJ	• P									(6*)
Panasonic	AG-HPX270PJ	• P									(6*)
Panasonic	AG-HVX200/201/200A/201A	• P									(6*)
Panasonic	AG-HPX175	• P									(6*)
Panasonic	AG-DVX100	• P									(6*)
Panasonic	AG-DVC80	• P									(6*)
Panasonic	AG-DVC30	• P									(6*)
Panasonic	AG-HMR10	• P									(6*)
Panasonic	AG-HCK10/10G	• P									(6*)
Panasonic	AJ-PX270PJ	• P									(6*)
Panasonic	HC-X1000	• P									(6*)
JVC	GY-HM600	• L	•	•							(7*)
JVC	GY-HM650	• L	•	•							(7*)
JVC	GY-HM850	• L	•	•							(7*)
Blackmagic	Cinema Camera			•							(8*)
Blackmagic	Production Camera 4K			•							(8*)
Blackmagic	Pocket Cinema Camera			•							(8*)
Blackmagic	Studio Camera			•							(8*)
Blackmagic	URSA			•							(8*)

- : compatible
- L : compatible, switch MVR901ECPL to LANC mode
- P : compatible, switch MVR901ECPL to Panasonic mode

(1*) Iris compatibility: behaviour depends on the camcorder model.
 (2*) not available: Zoom, Autofocus (tested with Sony SEL lenses).
 (3*) not available: Zoom, Autofocus, Autoiris.
 (4*) not available: Zoom, Autofocus, Autoiris, Iris.
 (5*) not available: Rec review, Autoiris, Iris.
 (6*) not available: Stand-by.
 (7*) not available: Stand-by.
 (8*) not available: Stand-by, Zoom.
 (9*) not fully compatible: Stand-by.

REMOTE CONTROL	ACCESSORIES			
	MVR901 APCL	522 AV	522 SCA	523 RIC
MVR901 ECPL		•	•	•
MVR901 ECLA		•	•	•
MVR901 EPLA	•	•	•	•
MVR901 ECEX				•
MVR901 EPEX	•			•
MVR911 ECCN				
MVR911 EICN				

DISCLAIMER
 The information contained in this document is subject of change without notice.
 Manfrotto makes no warranty and shall not be liable for any errors on information contained in this document.
 All trademarks are property of their respective owners.