

Camera Control Compatibility

Camera Control is available via the latest update of the Manfrotto Motion App and is compatible with Genie Micro, Genie Mini II, Genie II Linear and Genie II Pan Tilt.
 Camera control requires the USB cable that comes with your camera.

Tested and verified cameras for Camera Control:

Manufacturer	Model	Notes
Canon	M50	
Canon	1300D	
Canon	4000D	
Canon	40D	Video Start / Stop does not work on this camera
Canon	80D	
Canon	90D	
Canon	6D Mk II	
Canon	7D Mk II	
Canon	5D Mk IV	
Canon	5D S	
Canon	5D SR	
Canon	1DX Mk II	
Canon	1DX Mk III	
Canon	EOS R6	
Canon	EOS R5	
Canon	EOS R	
Nikon	Z50	
Nikon	Z5	
Nikon	D7500	
Nikon	D750	
Nikon	D780	
Nikon	D800	
*Sony	A9 II	
*Sony	A7R IV	
*Sony	A7S III	

*For USB camera control to work with Sony cameras those settings have to be adjusted inside the camera:

1. PC Remote: **On** (in old menu I USB Connection: PC Remote)
2. USB Power Supply: **Off**